



- A** = Main switch
- B** = OK
- C** = minus (reduce)
- D** = Plus (increase)