



Dear Tenant at Sognsveien 66

Read these instructions carefully for your own safety!

All apartments in Sognsveien 66 are equipped with a detector and an alarm connected to the Central Fire Alarm System.

If the alarm goes off in your flat, the local alarm will emit a pulsating high pitched noise and a red light will shine on the detector. When this happens a timer will start in the Central situated next to the mail boxes on the first floor, and you will have three (3) minutes before the Central starts the alarm in the rest of the building.

If the cause for the alarm is under control do the following:

1. If necessary open windows/doors to air the apartment.
2. Go to the Central to reset the alarm:
 - * Press the **GREY** button; this stops the timer.
 - * Press the **RED** button; this stops the alarm(s) in the apartment(s).
 - * Press the **GREEN** button; This resets the Central

If the cause for the alarm is **NOT** under control evacuate the building and call the Fire Department: 110

If the Central is not reset within the three minute timeframe, the alarm will start in all the apartments emitting a constant high pitched noise and everybody have to evacuate the building.

If the alarm in your apartment starts with a constant high pitched noise and the red light on the Detector does **NOT** shine, the alarm has been set off in one of the other apartments or by one of the detectors in the common areas. In this case you must evacuate the building at once!

Detectors must under no circumstances be covered or removed!